

FINISH

Use your fingers and firmly press on the screen from center out towards the edges to remove any air pockets.

Use the Microfiber Polishing Cloth and polish the screen with tempered glass on.

IMPORTANT: Once the tempered glass is fully adhered to the screen of your phone, it cannot be re-installed. You must discard it.



tzumi® ProGlass Full Screen GS7 Edge ITEM NO. 4317
Distributed by tzumi® INC. NY, NY, 10016 ©Copyright 2016 tzumi®
All Rights Reserved. Made In China. ProGlass is a trademark of tzumi®
Samsung and Galaxy S are both registered trademarks of Samsung
Electronics Co., Ltd. Subject to change without prior notice.

"Always There, Never Seen"

ProGlass™

curve series

FULL SCREEN
Curved Tempered Glass



tzumi®

"Always There, Never Seen"

ProGlass™

FULL SCREEN Tempered Glass Screen Protection

HD Clarity | 9H Hardness

Shatter & Scratch Resistant

Smooth Glass Surface

0.25 mm Thickness | Bubble-Free

Package includes:

- ProGlass Tempered Glass
- Multi-purpose Cleaning Wipe
- Microfiber Polishing Cloth
- Dust Removal Tape
- Instructions

IMPORTANT: Make sure your hands are clean and free of any lotions and oils prior to application. The screen must be completely free of dirt, oil or dust in order to successfully apply the tempered glass.

3-Step Quick Application

For best results, clean entire phone thoroughly prior to Step 1.

STEP 1 Clean Phone



Clean the screen of your phone using the enclosed ProGlass Cleaning Wipe.

Next, use the Microfiber Polishing Cloth and gently wipe the screen.

For final cleaning step, use the Dust Removal Tape to rid of any remaining dust particles.

Once this 3-step cleaning process is complete, do not touch the screen. Any dust or dirt/oil that is left on the screen will show under the ProGlass.

STEP 2 Peel Film



Peel/Pull Film Off of ProGlass.
Be careful not to touch the adhesive.

STEP 3 Apply Glass



Align ProGlass with the phone. Lay the tempered glass flat on top of the screen, adhesive side down.

Note: If you need to reposition the tempered glass, carefully lift up by its corner without touching the adhesive part. Re-adjust.

Firmly press with your thumbs in the center of the screen and watch the tempered glass adhere to the screen.