"Always There, Never Seen"

ProGlass TEMPERED GLASS SCREEN Protection



IMPORTANT: Make sure your hands are clean and free of any lotions and oils prior to application. The screen must be completely free of dirt, oil or dust in order to successfully apply the tempered glass.

4-Step Quick Application

For best results, clean entire phone thoroughly prior to Step 1.

STEP 1 - Applicator

Place Phone into Easy Applicator.



STEP 2 - Clean Phone

Clean the screen of your phone using the enclosed ProClass Cleaning Wipe. Next, use the Microfiber Polishing Goth and gently wipe the screen. For final cleaning step, use the Dust Removal Tape to rid of any remaining dust particles.

Once this 3-step cleaning process is complete, do not touch the screen. Any dust or dirt/oil that is left on the screen will show under the ProClass.



STEP 3 - Peel Film

Peel/Pull Film Off of ProGlass. Be careful not to touch the adhesive.



STEP 4 - Apply Glass

Align ProClass using the Easy Applicator. Lay the tempered glass flat on top of the screen, adhesive side down. Note: If you need to reposition the tempered glass, carefully lift up by its corner without touching the adhesive part. Re-adjust.

Firmly press with your thumbs in the center of the screen and watch the tempered glass adhere to the screen. Remove the Applicator out from the bottom of the phone.



FINAL STEP

Use your fingers and firmly press on the screen from center out towards the edges to remove any air pockets. Use the Microfiber Polishing Cloth and polish the screen with tempered glass on.

IMPORTANT: Once the tempered glass is fully adhered to the screen of your phone, it cannot be re-installed. You must discard it.