

Super Bass Mini Speaker



tzumi®



Superbass Speaker Manual

Jazz up the mood of your party and listen to high quality audio with the superbass speaker. This portable Bluetooth speaker can be your smart companion wherever you go, in picnics, beaches and outdoor adventures. Great for gatherings, the speaker is handy when you are heading outdoors or going far away from any plug socket. Its multifunction design supports playing songs wirelessly from mobile phones or smart devices. It can also play music from a Micro SD card and is compatible with personal computers, iPods, and other smart devices. Its intelligently designed 360 omni-directional sound and high bass makes you enjoy excellent quality audio anywhere on the go.


Package Contents:

Superbass Speaker

Micro USB Cable

User Guide

Product Overview & Functions



Compact and portable the Superbass Bluetooth speaker allows you to take your music along with you anywhere on the go.

Broad compatibility lets you play music from all compatible Bluetooth devices including smartphones, iPads, laptops, desktops and Micro SD cards.

Wireless freedom to take phone calls along with outstanding Bluetooth range of up to 10 meters.

Charging the Speaker

- The speaker has an internal rechargeable battery.
- The battery must be charged prior to use.
- Charging time is approximately two hours.
- When charging the power indicator will light-up red.
- Charging via USB wall adapter: Plug the provided micro USB cable into the speaker charging port, plug the USB end into a USB wall adapter.
- Charging via Computer: Plug the provided micro USB cable in the speaker charging port plug the USB end into an available USB port on a computer

Pairing Devices to the Bluetooth Speaker

- Make sure that the Bluetooth function is available on your cell phone or device.
- Specific pairing procedures will differ depending on cell phone.
- 1. Turn on the speaker by sliding the switch to the ON position.
- 2. Keep the distance between the cell phone and the speaker within 3 feet (for pairing only).
- 3. Enable the device Bluetooth function from its settings menu.
- 4. Select “BT-SPEAKER” from the Bluetooth device list.
- 5. Press “yes,” or “enter,” key to confirm pairing.
- 6. After successful pairing a tone will sound, your speaker is now ready to use.

Please note: once a device is successfully paired, the speaker will remember the device for subsequent uses.

Playing Audio via Bluetooth

- Once the device is paired.
- Turn on the speaker, the speaker will automatically enter Bluetooth mode

Playing Audio via Micro SD card

- Save songs on Micro SD card in MP3/WMA/WAV format
- Insert the Micro SD card into the card slot in the speaker
- Turn on the speaker it will automatically read the SD card.
- The speaker will adjust to Micro SD TF mode.

Music Control

- Play/Pause: press the play/pause button once
- Next Song: press the ►►/⏸ button once
- Rewind/Previous Song: press the ◀◀/⏮ button once
- Volume Up: press and hold the ►►/⏸ button
- Volume Down: press and hold the ◀◀/⏮ button

Answering Calls

- To answer a call: press the call button to answer an incoming call.
- To hang up a call: press the call button during a call to hang up.
- To reject on incoming call: press and hold the call button for 2 seconds to reject a call.

Troubleshooting

- **The music will not play from Micro SD card**
Make sure the music is in MP3 format and that the SD card is formatted prior to use.
- **Can’t turn the speaker on**
Check if the battery charge level is low and charge it again if necessary.
- **Can’t charge the speaker**
Check your power supply ensure that the output power supply is 5V and 1A.
Ensure that the charging cable and connecting cables are not damaged.
- **There is no sound**
Make sure that you are properly paired with the right Bluetooth device name BT-SPEAKER. If the connection fails disconnect and try again.

Specifications

- Bluetooth Version: 5.0
- Bluetooth Distance: up to 10 m
- Working Time: 1-2 hours
- Charge Time: 2 hours
- Power: External USB 5V
- Speaker Size: 52mm
- Speaker Output: 3W
- Battery Capacity: 300mAh
- Charging Voltage: 5V + 0.5 V

Battery Disposal

This product contains a lithium polymer battery. Lithium polymer batteries are environmentally safe when fully discharged. You cannot dispose this product along with household waste. It must be disposed of safely at a hazardous waste collection site, recycling facility or an electronic retailer that recycles. Check your local or state laws for disposal procedures.

Safeguards:

- Keep the unit away from heat source, direct sunlight, humidity, water or any other liquid.
- Do not expose the device to extremely high or low temperatures, as it may damage the battery.
- Do not operate the unit if it has been wet or moist to prevent against electric shock and/or injury to yourself and damage to the unit
- Do not use the unit if it has been dropped or damaged in any way.
- Repairs to electrical equipment should only be performed by a qualified electrician. Improper repairs may place the user at serious risk.
- Keep the unit out of reach of children.
- This unit is not a toy.