



# Sport Series Magnetic Earbuds



**tzumi**

## PRODUCT OVERVIEW & FUNCTIONS



## CHARGING YOUR EARBUDS

Charging the battery is recommended prior to use. It takes approximately 1.5 hours to fully charge your earbuds (from depleted unit).


RED Light - Charging      BLUE Light- Fully Charged

## CHARGING VIA COMPUTER

Using the provided Micro USB cable, connect the Earbuds into the USB port on a computer or laptop.

## CHARGING VIA AC ADAPTER WALL CHARGER

Using the provided Micro USB cable, connect the Earbuds into the USB port on AC Adapter Wall Charger.



## PAIRING EARBUDS TO BLUETOOTH DEVICE

Make sure the Bluetooth function is available on your electronic device. Specific pairing procedures may vary slightly depending on the device. For detailed information, please refer to the User Guide for your electronic device.

- If no device connection is made within 5 minutes of the earbuds being switched on, the earbuds will automatically be switched off to save power.
- After successful pairing, devices will remember each other and automatically pair the next time.

1. Keep the distance between the cell phone and the earbuds within 3 feet (for pairing only).
2. Press the button for a couple seconds to turn on the earbuds. You will hear prompt "Power On" and see flashing blue lights.
3. Pairing mode will begin automatically and you will hear prompt "Pairing" and see flashing blue and red lights.
4. Activate the Bluetooth function on your cell phone to search for Bluetooth devices. Select "Tzumi-Sport" in the device display list.

## PAIRING EARBUDS TO BLUETOOTH DEVICE continued

5. When Bluetooth pairing is successful, you will hear prompt "Connected" and blue lights will flash quickly twice every few seconds.
6. Earbuds are now ready for use.

## EARBUD CONTROLS OVERVIEW

Power ON / OFF

BUTTON	CONTROL	FUNCTION
	Press/Hold	Power ON / OFF

## Music Controls

BUTTON	CONTROL	FUNCTION
	Press	Play
	Press again	Pause / Resume
	Press/Hold	Go to Next Song
	Quick Press 1 x	Volume UP
	Press/Hold	Go to Previous Song
	Quick Press 1 x	Volume DOWN

## Phone Controls

BUTTON	CONTROL	FUNCTION
	Press	Answer / End Call
	Press twice	Reject Call
	Quick Press 2x	Redial last call

## IMPORTANT SAFEGUARDS

- Do not use this unit for anything other than its intended use.
- Keep the unit away from heat source, direct sunlight, humidity, water or any other liquid.
- Do not expose the device to extremely high or low temperatures, as it may damage the battery.
- Do not operate the unit if it has been wet or moist to prevent against electric shock and/or injury to yourself and damage to the unit.
- Repairs to electrical device should only be performed by a qualified professional. Improper repairs may place the user at serious risk.
- Keep the unit out of reach of children.
- This unit is not a toy.

## SPECIFICATIONS

Bluetooth Version: V5.0  
Distance: Up to 33 ft  
Battery: Rechargeable Polymer Lithium 70mAh  
Frequency: 20Hz-20KHz  
Input: 5V/60mA  
Standby Time: Up to 65 hours  
Charging Time: Up to 1.5 hours  
Play Time: Up to 5 hours  
Talk Time: Up to 6 hours

Tzumi® Sport Series Earbuds  
Distributed by Tzumi Inc. NY, NY 10016 ©Copyright 2018  
Tzumi. All Rights Reserved. Made in China. All brands are registered trademarks of their respective companies.

FCC ID: QIF-E20