

ColorShape LED flex light 16'



User Guide

Introduction & Features

The auraLED ColorShape 16' LED Flex Lights are perfect for lighting up any outdoor space and are suitable for countless applications. From ceiling, to cabinets to under furniture lighting, they brighten up your surroundings. The LED Flex Light is also perfect for holiday decorations, outdoor pool or hot tub areas and backyard BBQ fun. It includes a wireless remote controller, which provides you with the freedom to customize your selection of colors and set the ideal brightness, rhythm, and color scheme.

- Four Modes (Flash, Strobe, Fade, Smooth) – 16 Distinct Colors
- Adjustable Color Intensity & Brightness via Wireless Remote Control
- Relieve Eyes from Fatigue
- Create Ambiance & Unique Atmosphere

What's In The Box?

- LED Flex Light with attached AC Adapter & Controller
- Wireless Remote
- User Guide

Using The LED Flex Light


1. Locate a nearby AC outlet to where you plan to connect the LED Flex Light.
2. Make sure that you are satisfied with the coverage area of the LED Flex Light prior to setting it in place. Make sure that the AC Adapter is placed near the plug and has enough slack to reach safely. The remote receiver must also be visible in order to work properly.
3. Remove the battery cover on the back of the remote, insert two AAA batteries and close the cover.
4. Plug in the LED Flex Light into an AC outlet.
5. Press the ON button on the remote to turn on the LED Flex light.
6. Refer to the color combinations settings on the remote to customize your LED Flex Light.

Wireless Remote Controls

Positioning the receiver: As this is an infrared remote, the receiver should be in the line of sight of the remote to function properly. The remote is powered by two AAA batteries.

Wireless Remote Controls

Buttons 1 and 2 can be used to control the effects and speed of buttons 6, 7, 8, 9.



1. Brightness (UP) /Flash Control (QUICK)
2. Brightness (DOWN) /Flash Control (SLOW)
3. Power OFF
4. Power ON
5. LED color buttons/ 16 colors
6. Flash (Changes Instantly) Red > Green > Blue
7. Strobe (Changes Instantly) Red > Green > Blue > Yellow > Light green > Purple > White
8. Fade (Changes Gradually) Red > Green > Blue
9. Smooth (Changes Gradually) Red > Green > Blue > Yellow > Purple > Light Green > White

Safeguards:

- Keep the LED Flex Light away from flammable objects.
- The adapter and control box are not waterproof, keep away from water.
- Always make sure that all parts have been connected properly to avoid short circuit.
- Do not connect the LED Flex Light to the power source until the installation has been completed.
- Do not cut any part of the LED Flex Light or its connectors.
- Always make sure that the remote receiver is not covered or blocked. This will ensure proper operation using the remote control.
- If this product malfunctions, please do not try to repair it yourself, take it to a qualified electrician.

Specifications:

- Input: 110V
- Power Consumption: 60W
- LED Chip: 360Pcs
- Color: RGB
- LED Strip: 16' (192")
- Working Temperature: 149°F
- Working Humidity: 5-140 %RH
- Weatherproof: IP65 for the rope, the AC adapter and control box are not water resistant.

If you have any other questions or issues with product use and/or care, please contact tzumi Technical Support at: support@tzumi.com or 1-855-GO-TZUMI.



AuraLED ColorShape Flex light. Distributed by tzumi Inc. NY, NY 10016. © Copyright 2022 tzumi Inc. All Rights Reserved. Made in China. Other trademarks and trade names are those of their respective owners. Subject to change without prior notice.