40in.
16 PANEL

BareBones™

DOG PLAYPEN



USER GUIDE

STEP ONE



Stand a Panel or Panel Door upright.

STEP TWO

Slide a Rod into the slot between the Panel or Panel Doors.

STEP THREE

Push a Rubber Rod Cover onto the exposed end of the Rod at the bottom.

STEP FOUR

Repeat steps 1-3 until you reach the desired size and shape for your pen.



BareBones™

DISTRIBUTED BY: tzumi pets New York, NY 10016

If you have questions about setting up or using this product, we are here to help! Call or email us, and an experienced customer support representative will be happy to assist you:
1-855-GO-TZUMI or **support@tzumi.com.**