

zip  
vac



USER GUIDE



# Table of Contents

1.	Introduction	.....
2.	What's in the Box	
2.1	Get Familiar with Your ZipVac	.....
3.	Setup	
3.1	Using the Vacuum	
3.2	Cleaning the Vacuum	
3.3	General Tips	.....
4.	Precautions	.....
5.	Polarization Instructions	.....
6.	Specifications	.....
7.	Servicing of Double-Insulated Appliances	.....
8.	Part 15 of FCC Rules	



Thank you for choosing one of our exciting and innovative products. We strive to bring you the latest cleaning technology that provides lifelong value and keeps you ahead of your chores.

Vacuuming shouldn't feel like a workout—especially when you are only dealing with small spills and messes. This super-lightweight, portable vacuum switches from a traditional vacuum cleaner to a handheld unit in seconds, making it a simple, convenient solution to your basic vacuuming needs.

- **Weighing under 5lbs., its super-lightweight design makes cleaning a breeze.**
- **Quickly switches from a traditional vacuum cleaner to a handheld unit in seconds.**
- **Includes a built-in slim nozzle that lets you vacuum tight corners and hard-to-reach spaces.**

**Get ready to clean in  
FLOOR WHEEL DRIVE!**





## 2

## What's in the Box

Your new ZipVac is easy and quick to assemble.  
Let's start with all the parts you will be taking out of the box:

**Handheld Vacuum Base**

**Extender Handle**

**Dustbin with Slim Nozzle**

**Floor Extension**

**User Guide**



## 2.1 Get Familiar with Your ZipVac

**Power Cord**  
20 ft. long



**Extender Tube & Handle**  
Attach for upright vacuuming

**Built-in Slim Nozzle**  
Ideal for tight corners & hard-to-reach spaces; quick flip down design



**Handheld Vacuum Base**  
Compact, with easy ON/OFF controls

**HEPA Filter**  
Removable & easy to clean

**Large Dustbin**  
Convenient & quick snap on/off design

**Floor Extension**  
Low profile, for effective multi-surface cleaning





## 3

# Setup

1. Insert the handle into the top of the vacuum until it clicks into place. Make sure it is securely installed.
2. Insert the floor extension or unfold the slim nozzle into the vacuum's suction opening.

## 3.1 Using the Vacuum

1. There are two ways to clean with the vacuum: standard mode, using the floor extension, or handheld mode, using the built-in slim nozzle.
  - To switch to handheld mode, remove the extender handle from the vacuum by pressing the release button on the side of the unit and pulling the tube out.
  - Remove the floor extension from the suction opening, then flip the built-in slim nozzle down to install it.
2. Plug the vacuum into the nearest wall outlet.
3. The power switch is located on the handheld vacuum base. "I" powers the vacuum ON; "O" turns the vacuum OFF.
4. Start cleaning!

## 3.2 Cleaning the Vacuum

### Dustbin

1. Press the release button at the bottom of the dustbin to empty it.
  - For an easier clean, remove any nozzles from the suction opening.

### HEPA Filter

1. Press the release button on the handheld vacuum base to open the dustbin, then remove the HEPA filter.

## Continued...

2. Wash the HEPA filter under running water and let it air-dry.
  - If you are replacing the HEPA filter, there is no need to wash it. Throw the old one out and insert a new one instead.
3. Make sure the HEPA filter is completely dry before re-inserting it.

## 3.3 General Tips

- The floor extension and its wheels can sometimes become jammed, in which case they will need to be cleaned to maintain the vacuum's cleaning efficiency. To do this, make sure the vacuum is powered off, then carefully remove all obstructions.
- It is recommended that the HEPA filter be changed every 3 months.
- The slim nozzle is best used for cleaning corners, edges, radiators, drawers, etc.

## 4

## WARNINGS & IMPORTANT SAFETY INSTRUCTIONS

When using this electrical appliance, basic precautions should always be followed.

Read the following instructions before using this vacuum.

Keep this user guide for future reference.

**WARNING: To reduce the risk of fire, electric shock, or injury:**

1. Do not leave the vacuum unattended while it is plugged in. Unplug the vacuum from the outlet when it is not in use and before cleaning it.
2. Do not use this vacuum outdoors or on wet surfaces.
3. Do not allow this vacuum to be used as a toy. Extra caution is necessary when using this appliance near children.
4. Never insert the extender tube into the vacuum while the slim nozzle is installed.

## Continued...

5. Only use this vacuum as described in this user guide. Only use attachments recommended by the manufacturer.
6. Do not use this vacuum with a damaged cord or plug. If the vacuum is not working as it should, or has been dropped, damaged, left outdoors, or dropped in water, return it to a service center.
7. Do not pull or carry the unit by the cord, use the cord as a handle, close a door on the cord, or pull the cord around sharp edges or corners. Do not run the vacuum or any other object over the cord. Keep the cord away from heated surfaces.
8. Do not unplug the vacuum by pulling on the cord. To unplug, grasp the plug instead.
9. Do not handle the plug, the power cord, or the vacuum with wet hands.
10. Do not insert any objects into any opening on the vacuum. Do not use this appliance with any blocked openings. Keep this vacuum clean and free of dust, lint, hair, or anything that can reduce airflow.
11. Keep hair, loose clothing, fingers, and all parts of the body away from all openings and moving parts.
12. Turn the vacuum OFF before unplugging it from the power source.
13. Exercise extra caution when using this vacuum on stairs.
14. This appliance is provided with double insulation. Use only identical replacement parts. See instructions for Servicing of Double-Insulated Appliances.
15. Never operate the vacuum without the dustbin or the HEPA filter installed.
16. Clean the HEPA filter by hand, under running water only.
17. Do not use artificial heat sources to dry the HEPA filter. Air-dry only.
18. Do not use this vacuum to pick up any burning or smoking objects, such as cigarettes, matches, or hot ashes.

## SAVE THESE INSTRUCTIONS

## 5 Polarization instructions

To reduce the risk of electric shock, this appliance has a polarized plug (one blade is wider than the other). This plug will only fit in a polarized outlet one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician to install a proper outlet. Do not modify the plug in any way.

## 6 Specifications

---

<b>Power</b>	400W MAX
<b>Suction Power</b>	≥12 kPa
<b>Noise</b>	≤78 dB
<b>Rated Voltage</b>	110-120V/60Hz
<b>Dustbin Capacity</b>	34 oz.
<b>Size</b>	44 x 6 x 10 in.
<b>Weight</b>	About 3.53 lbs.

## 7 Servicing of Double-Insulated Appliances



In a double-insulated appliance, two systems of insulation are provided instead of grounding. No grounding means is provided on a double-insulated appliance, nor should a means for grounding be added to the appliance. Servicing a double-insulated appliance requires extreme care and knowledge of the system, and should be done only by qualified service personnel. Replacement parts for a double-insulated appliance must be identical to the parts they replace.

## 8 Part 15 of FCC Rules

**CAUTION:** Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this appliance.


**NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

ionvac ZipVac, Distributed by tzumi Inc. NY, NY, 10016.  
©Copyright 2025 tzumi Inc. All Rights Reserved. Made in Cambodia.

All pictures shown are for illustration purposes only.  
Actual product may vary due to product enhancement.  
Subject to change without prior notice.





**If you have any questions  
or need help setting up  
or using your ZipVac,  
email us at [support@tzumi.com](mailto:support@tzumi.com)  
or call 1-855-GO-TZUMI.**

For more details on  
the ionvac family of products,  
or to check out more brilliant  
innovations, visit: [www.tzumi.com](http://www.tzumi.com).

**tzumi**®  
live awesome.